



Pos.	Qty.	Art.No.	Description	Pos.	Qty.	Art.No.	Description
1	1	9145-2	Frame	27	2	9145-55	Chain 1/2 x 1/8", 42 l, incl.lock
2	1	9030-6	Support tube, rear	28	2	9145-145	Crank axle
3	2	9100-5	Plastic cap, blue	29	1	9145-146	Crank bearing arm, right
4	2	9010-12	Transport wheel, complete	30	1	9145-147	Crank bearing arm, left
5	2	1066	Plastic cap, white	31	2	9045-50	Arm extension fastener compl.
6	1	9145-10	Cover with decals, complete	32	2	9145-49	Spring for above
	5	21015-5	Mounting screw for cover	33	1	9145-60	Crank arm, left
7	1	9145-18	Rubber belt	34	1	9145-63	Crank arm, right
8	1	9145-20	Combination key	35	2	9045-65	Collar
9	1	9145-24	Flywheel 11kg, complete	36	1	9145-66	Double keyed collar
10	1	9045-27	Axle length 160 mm 26g			9145-72	Meter set compl. (for all 881)
11	1	9010-38	Tension Pin 5x18 mm	37	1	9371-68	-Digital meter
12	2	9145-50	Washer 10x18 mm	38	1	9326-162	-Crank sensor with cable
13	2	9145-28	Bearing bushing	39	1	9145-69	-Holder for sensor
14	2	19001-6	Ball bearing 6001-2z	40	1	9371-67	-Holder for digital meter
15	1	9000-15	Lock ring SgH 028		1	9326-164	-Magnet
16	2	2420-49	Sprocket nut	41	1	9300-205	Pedal, pair
17	2	1210	Sprocket 14t		1	9300-207	Footstraps, pair
18	1	9145-30	Brake belt, complete	42	1	9045-70	Handle, pair
19	1	9145-32	Indicator	43	1	9145-75	Grip, pair
20	2	9145-92	Plate	44	1	9045-71	Hand guard
21	1	9145-33	Spring		1	9145-550	Decal set for 881 E
22	1	9145-34	Bracket	45	1	9145-100	transport handle
23	1	9145-136	Tension lever, complete	46	1	9145-101	Locking pin with chain
24	1	9145-140	Handwheel, complete	47	1	9045-101	Wall bar fastener
25	1	6720	Crank bearing set, complete		1	9145-150	Screw, washer and nut set
26	2	9007-36	Chain wheel, 34T				